



FIGURE 9 - CABIN ENCLOSURE (CONT)

KEY	ITEM NO.	PART NUMBER	1	2	3	4	NOMENCLATURE	UNITS PER ASSY	USAGE
8	1619	145-31819					Engagement Assy - Canopy Latch Hook - - - - -	1	2-1050
9	1620	145-31819-3					Bracket - Hook Engagement - - - - -	1	2-1050
10	8345	4S3D10-16					Spacer - Locking Roller - - - - -	1	1051 & Subs
11	8351	4S3D616-14					Spacer - Locking Roller - - - - -	1	1051-1784
12		AN520-10R16					Screw - Round Head Machine (Fine Thread) - - - - -	1	2-1050
13		NAS221-18					Screw - - - - -	1	1051 & Subs
14		AN365-1032					Nut - Self Locking - - - - -	1	2-1050
15	1451	145-31801-3SA#5					Skin Assy - Sta 54 to 101 Upper LH (Inc. Stiffener)	Ref	
	1452	145-31801-3SA#6					Skin Assy - Sta 54 to 101 Upper RH (Inc. Stiffener)	Ref	
16	9059	482J3					Handle - Cabin Entrance - - - - -	1	
		NAS205-10					Screw - - - - -	4	
		AN365-1032					Nut - Self Locking - - - - -	4	
17	1600	145-31801-104					Sliding Canopy - Complete - - - - -	1	
18	1604	145-31801-17					Window - Front Side LH (Untrimmed) - - - - -	1	
	1605	145-31801-18					Window - Front Side RH (Untrimmed) - - - - -	1	
19	1606	145-31801-23					Window - Rear Side LH (Untrimmed) - - - - -	1	
	1607	145-31801-24					Window - Rear Side RH (Untrimmed) - - - - -	1	
20	1608	145-31801-45					Window - Rear (Untrimmed) - - - - -	1	
21	1609	143-31852-5					Retainer - Glass (Rubber) - - - - -	NOTE	
22	1613	143-31853-5					Lock - Glass (Rubber) - - - - -	NOTE	
		Items 1609 and 1613					Used With Items 1606 and 1607 Glasses		
23	1610	143-31852-4					Retainer - Glass (Rubber) - - - - -	NOTE	
24	1614	143-31853-4					Lock - Glass (Rubber) - - - - -	NOTE	
		Items 1610 and 1614					Used With Items 1604, 1605 and 1608 Glasses		
25	1601	145-31801-32					Cover - Baggage Compartment - - - - -	1	
26	1621	145-31801-34					Reinforcement - Canopy - - - - -	2	
27	1622	145-31801-43					Track - Canopy Rear LH - - - - -	1	
	1623	145-31801-44					Track - Canopy Rear RH - - - - -	1	
28		NAS205-11					Screw - - - - -	2	
29	1647	145-31801-50					Canopy Stop - Birchwood Block - - - - -	2	
30		AN960-8					Washer - Plain - - - - -	1	
31		AN365-1032					Nut - Self Locking - - - - -	1	
32		AN520-10R30					Screw - Round Head Machine (Fine Thread) - - - - -	1	
33	1624	145-31821					Handle - Cabin Exterior - - - - -	1	2-1500
	1624-10	145-31824					Handle - Cabin Exterior - - - - -	1	1501 & Subs
34	1625	145-31828					Handle - Cabin Interior - - - - -	1	
35		AN565A8H8					Set Screw - - - - -	1	
36	1626	145-31814					Support - Canopy Latch Cover Plate - - - - -	1	2-100
	1626-10	145-31814-3					Support - Canopy Latch Cover Plate - - - - -	1	101 & Subs
37	1627	145-31816					Pulley Assy - Cockpit Enclosure Canopy Latch - - - - -	1	
38	1628	145-31823					Spring - Canopy Latch Hook Closure - - - - -	1	
39	1629	145-31815-22					Bushing - - - - -	1	
40	1630	145-31817					Hook Assy - Cockpit Enclosure Canopy Latch - - - - -	1	
41	1631	145-31818					Housing Assy - Cockpit Enclosure Canopy Latch - - - - -	1	2-100
	1631-10	145-31818-22					Housing Assy - Cockpit Enclosure Canopy Latch - - - - -	1	101 & Subs
42		NAS221-11					Screw - - - - -	4	
43		AN960-D10					Washer - Plain - - - - -	4	
44		AN365-1032					Nut - Self Locking - - - - -	4	
45	1632	145-53012-19					Cover Plate - Headliner Assy - - - - -	1	2-100
	1632-10	145-53012-25					Cover Plate - Headliner Assy - - - - -	1	101 & Subs
46	1633-10	145-31815-41					Cable & Pin Assy - Canopy Locking - - - - -	1	251 & Subs
47	1633	145-31815-41SA#1					Cable Assy - Canopy Locking - - - - -	1	251 & Subs
48	1633-20	145-31815-41SA#2					Pin Assy - Canopy Locking - - - - -	1	251 & Subs
49	1634	145-31822					Spring - Canopy Locking Projector - - - - -	1	
50	1635	145-31830					Track Assy - Canopy Operating Fwd. (Inc. Rollers) - - - - -	2	2-1789
	1635-10	145-31831					Track Assy - Canopy Operating Fwd. (Inc. Rollers) - - - - -	2	1790 & Subs
51		NAS205-10					Screw - - - - -	2	
52	9071	26NKM02					Cap Nut - - - - -	4	2-1789
53	1636	143-31851-5					Roller - Front Track Male - - - - -	4	1790 & Subs
	1636-10	145-31832-4					Roller - Front Track Male - - - - -	4	
54	8030	4B18-3-125					Bushing - - - - -	2	
55	1637	145-31827					Support Assy - Canopy Track Rear Roller - - - - -	1	
56	8030	4B18-3-125					Bushing - - - - -	2	2-1789
57	1638	143-31851-3					Roller - Rear Track Male - - - - -	2	1790 & Subs
	1638-10	145-31832-3					Roller - Rear Track Male - - - - -	2	2-1789
58	1639	143-31851-4					Roller - Rear Track Female - - - - -	2	1790 & Subs
	1639-10	145-31832-5					Roller - Rear Track Female - - - - -	1	2-1546
59	1640	145-31862					Cable Assy - Emergency Release (Includes Handle) - - - - -	1	1547 & Subs
	1640-10	145-31867-3					Cable Assy - Emergency Release (Includes Handle) - - - - -	1	
60	1641	145-31858-3					Bracket Assy - Opening Mech Lower Pulley Sta 179.75 - - - - -	1	
61	1642	145-31857-3					Bracket Assy - Opening Mech Lower Pulley Sta 179.75 - - - - -	1	
62	1643	145-31856-3					Bracket Assy - Opening Mech Lower Pulley Sta 179.75 - - - - -	1	
63	1644	145-31855-3					Bracket Assy - Opening Mech Floating Pulley - - - - -	1	
64	1645	145-31859					Spring - Canopy Emergency Operating - - - - -	1	
65	1646	145-31860					Pulley - Anti-friction Bearing Control - - - - -	5	
66		AN210-2A					Pulley - Anti-friction Bearing Control - - - - -	1	
67		AN210-1A					Pulley - Anti-friction Bearing Control - - - - -	1	
68	1648	145-31829-2					Track Assy - Fuselage Enclosure RH - - - - -	1	
69	1650	145-31829-5					Seal - Seal - Sponge Rubber - - - - -	1	
	1649-10	145-31829A#3					Track Assy - Fuselage Enclosure LH - - - - -	1	
	1650	145-31829-5					Seal - Sponge Rubber - - - - -	1	